

Furka® F-HED2008 Series hydraulic power unit for safety / emergency brakes




Table of contents

1. Safety regulations	4
1.1 General advice	4
1.1.1 Qualification of the personnel	4
1.2 Safety and warning symbols	4
1.3 General hazard warnings	4
1.4 Warranty	5
1.5 Non-designated use	6
2. Valve controlled electro-hydraulic thruster	6
2.1 Basic function	6
2.2 Storage, transport and packaging	7
2.3 Technical parameters	7
2.3.1 Suitable operating environment	7
2.3.2 Motor duty / Load cycles	8
2.3.3 Supply voltage and IP protection classes	8
2.3.4 Safety and maintenance rules	8
2.3.5 Interface requirements	8
2.4 Tool list	9
3. Structure, installation and operation of F-HED2008	9
3.1 F-HED2008 structure	9
3.2 Installation	10
3.2.1 Set-up	10
3.2.2 Hydraulic connection	10
3.2.3 Electrical connection	10
3.3 Operation of F-HED2008	11
3.3.1 Oil charge	11
3.3.2 Commissioning	13
3.3.2 Manual release operation	13
4. Operation and maintenance	14
4.1 Pre-operation	14
4.2 Check	14
4.2.1 Mechanical	14
4.2.2 Electrical	14
5. Trouble shooting	16

Date: 28.03.2023		AW



5.1 Motor cannot be started	16
5.2 F-HED2008 does not provide enough power, brake cannot be released	16
5.3 Motor starts frequently	16
5.4 Motor starts continuously	16
5.5 Troubleshooting	17
5.6 Common errors during commissioning	17
5.7 Disposal	18
6. Annex	19

List of illustrations

Figure 1: Hydraulic diagram, Valve logic	7
Figure 2: Main dimensions	9
Figure 3: Top view	10
Figure 4: hydraulic hose connection	10
Figure 5: Electrical connection	11
Figure 6: Top view thruster cover	11
Figure 7: Throttle valve cover and pressure gauge	12
Figure 8: Pressure hose connection	12
Figure 9: Manual release operation	14
Figure 10: LED display	15
Tightening torques	19

Date: 28.03.2023		AW

1. Safety regulations

1.1 General advice

The safety of your **F-HED2008** (thruster) depends on proper and regular inspection and maintenance. Study the manual before starting the installation. If in doubt, please don't hesitate to contact our service-department or your local retailer.




1.1.1 Qualification of the personal

The activities described in this documentation require elementary knowledge of mechanics, electrics and hydraulics as well as the safe handling of the relevant technical terms.



Only trained specialists and instructed persons under the supervision of a specialist are authorised to carry out the activities described in this documentation.

A specialist is a person who is able to recognise hazards and take appropriate safety measures on the basis of his technical training, knowledge and experience. Furthermore, a skilled worker is obliged to comply with the relevant professional rules.

1.2 Safety and warning symbols





	Warning of personal injury	This signal indicates a threat of danger. If this danger is not avoided, this will result in death or serious injuries.
	Warning of product damages	This symbol indicates a warning which may contribute to prevent material or machine damage.
	General advice	This symbol indicates information that helps to avoid adverse results and conditions.

1.3 General hazard warnings

	When operating the THRUSTER, strong electro-magnetic radiation may occur, which is why persons with pacemakers are advised not to stay in the vicinity.
	A sudden start-up of the installation endangers the life of the maintenance personnel! Secure the drive and the installation against any accidental movement before starting any work! Reading the operating instructions is indispensable.

Date: 28.03.2023		AW

- The following applies to all work and operations with the THRUSTER: **Safety first**
- Don't use any mechanical devices to block the brake.
- Ensure, that **the drive** is disconnected from the electrical power supply.
- Ensure, that **the brake** is disconnected from the electrical power supply.
- Any electrical work is only to be done by a trained electrician.
- Only use original Furka® spare parts
- The THRUSTER must not be disassembled.
- **Never open the thruster or the screw plug when it is hot! Escaping hot oil may cause burns!**
- **Before repair or refilling, let the unit cool down to room temperature!**
- Furka® THRUSTERS are fully factory tested prior to delivery and are supplied in a perfect condition.

	Caution: Hydraulic fluid can be hazardous to health, contact with skin and eyes can cause serious damage. Follow the instructions in the safety data sheets of the hydraulic fluid manufacturer with regard to the protection of personnel and safety.
	Caution: Hydraulic fluid may be harmful to the environment. It is therefore recommended that the unit is installed incl. a drip pan to prevent environmentally harmful fluid escaping through leaks what can lead to contamination.
	Caution: Intentional or unintentional tampering with valves, accessories or components is not permitted. Opening a throttle valve can e.g. cause a load to fall freely.
	Attention: All installation, maintenance, dismantling and replacement work on the hydraulic unit and its components may only be carried out in compliance with the the safety instructions. During this work the hydraulic system must be depressurised (pressure 0) and the drives driven by the unit must be unloaded (load 0).

1.4 Warranty

The warranty and its duration depends on the contract. For details on the supplier's warranty please refer to the terms of the contract. Any warranty- or liability claims are excluded in case they occur because of one or more of the following conditions:

- Non-designated use of the F-HED2008.
- Improper handling, setup, operation and maintenance of the F-HED2008 by the operating company.
- Neglect of the regulations and notes in this manual concerning transport, setting up, operation or maintenance of the F-HED2008.
- Improper maintenance and repairs of the F-HED2008.
- Improper monitoring of components, which are prone to wear.
- Catastrophes, external objects and forces and force majeure.
- Changes at the F-HED2008 without approval of Furka®.

Date: 28.03.2023		AW

- The information in this manual has been checked thoroughly. Nevertheless we can't accept liability for errors.

1.5 Non-designated use

Only the use described in this document is permitted. The risks associated with improper use lie solely with the user and Furka Antriebstechnik GmbH accepts no liability.

Unintended use is defined as

Disregard


- of the operating pressure level in the installation drawing,
- of the specifications regarding the pressure fluid,
- the correspondingly deviating operating and environmental conditions.

2. Valve controlled electro-hydraulic thruster

2.1 Basic function

The F-HED2008 is an independent unit that consists of motor, gear pump, valves and protective casing completed by a CMU integrated control device. Typical applications are safety/emergency brakes, actuator for industrial valves, gates, as well as rotating, pivoting and clamping devices. For basic functionality please refer to figure 1.

The control and monitoring unit controls the motor and the relay and monitors the hydraulic functions. Braking times, error types and times as well as information about the motor status can be read out via a LED display.



Working sequence for electric elements ("+" means the element be energized)

Action \ Element	YV	SP	M	T	BMS
brake release(remote)	+		+		+
brake hold	+	upper limit	-		+
system compensate pressure	+	lower limit	+		+
brake close(remote)	-		-		-
Alarm	motor continuously operates over 1s				+
	while brake holding, motor starts over one time in 5min				+
	oil temperature is up to 70°C				+

Power supply of electric elements: M:380V; SP, YV: 24VDC

Figure 1: Hydraulic diagram, Valve logic

Pos.	Description	Pos.	Description	Pos.	Description
1	Motor	6	Hand pump	11	Throttle valve
2	Gear pump	7.1 7.2	directional poppet valve	12	Pressure switch
3	Filter	8	Safety valve (Direct-acting relief valve)	13	Plug-in Coupling
4.1 4.2	Oil sight glass	9	Check valve	14	Hose
5	Temperature switch	10	Direct-acting relief valve	15	Pressure gauge

2.2 Storage, transport and packaging

The THRUSTER is shipped ready to mount.

- F-HED2008 are shipped ready to use complete with hydraulic fluid.
- Store and transport the F-HED2008 dust- and waterproof.
- Protect the F-HED2008 during the whole storage- and transport time against damage.

In case of additional painting, do NOT contaminate:

- Electrical components
- Signs and plates

If the THRUSTER isn't installed directly after delivery heed the following instructions:

Store and / or transport the F-HED2008 dust- and waterproof with drying agent until installation.

- Protect the brake/F-HED2008 against external damages during the complete storage- / transport-period.



Note!

**Depending on the type, the F-THRUSTER has a weight of up to 56kg.
Always use a proper lifting device to transport the THRUSTER! Danger of injury.**

2.3 Technical parameters

2.3.1 Suitable operating environment

- 1) Ambient temperature -30 °C - +60 °C
- 2) Indoor, outdoor, sea side
- 3) Rain-, rust-, wind-, sand-, and vibration-proof

Date: 28.03.2023		AW

2.3.2 Motor duty / Load cycles

- 1) Rating: S3 intermittent operation duty
- 2) Unlimited working cycles
- 3) Maximum operating frequency is 180c/h

2.3.3 Supply voltage and IP protection classes

- 1) IP protection class of THRUSTER is IP66
- 2) IP protection class of the control box is IP67
- 3) Supply voltage: 340...420V, 50/60Hz
- 4) Power: 3kW

Voltage fluctuations should not exceed $\pm 10\%$ of the rated voltage.

It is not permissible to operate the THRUSTER with a supply voltage and frequency other than those specified on the nameplate.

2.3.4 Safety and maintenance rules



Before installing or mounting the hydraulic unit, make sure that the relevant system parts are depressurised. Never remove screw connections, hoses and couplings before the hydraulic unit has been depressurised!

- 1) The operator is responsible for the cleanliness of the THRUSTER and brake.
- 2) Do not make any changes (type and size) on electrical or hydraulic components.
- 3) The hydraulic flow valve may only be adjusted by trained personal.
- 4) The hydraulic safety valve and the overflow valve may only be adjusted by trained personal.
- 5) Changes in the CMU software may be only implemented by qualified personal.
- 6) When wiring the motor, make sure that the direction of rotation of the motor is correct.
- 7) The THRUSTER must not be operated in case the oil level is too low.
- 8) Only use oil that is specified in this manual.
- 9) Before disassembling the THRUSTER make sure that supply and control voltage have been switched off and that there are no constraining forces on the THRUSTER.

2.3.5 Interface requirements

- 1) Oil supply connection thread is M16x1.5
- 3) Base plate connection via 4 x $\varnothing 10$ mm bores, 232mm x 171mm (length x width)

Date: 28.03.2023		AW

4) Water-proof cable gland of control cable M20×1.5, cable diameter Ø 6~12mm (optional)

2.4 Tool list

Description	Tools
Control unit (CMU)	Allen key 3mm
Conduit gland	Spanner 27mm
Terminal bolt	Screw driver PH2 or straight 5mm
Top cover, oil filler plug	Allen key 6mm
Solenoid valve, overflow valve, throttle valve locknut	Spanner 17/19
Pressure gauge, pressure hose	Spanner 14/17

3. Structure, installation and operation of F-HED2008

3.1 F-HED2008 structure




Figure 2: Main dimensions

The electrohydraulic thruster (F-HED2008) described in figure 2 is a compact thruster consisting of motor-pump unit, valve group and electric control device.

Date: 28.03.2023		AW

3.2 Installation

3.2.1 Set-up

The thruster must be installed vertically. Fixing screw size is M8 (tightening torques as per table in the annex). In case of extreme vibrations, the unit should be placed on damping pads.




Figure 3: Top view

3.2.2 Hydraulic connection





Figure 4: hydraulic hose connection

The THRUSTER has two threads size M16 x 1.5 for oil supply. Please use only male stud fittings with 24° taper (tightening torque 35Nm). Max. operation pressure is up to 320bar.

3.2.3 Electrical connection



Danger!

The applied electrical voltages are dangerous to life! The electrical connection and all other electrical tasks must only be done by a **trained electrician!**

Connect the phases to L1, L2, L3 and PE in the control box of the hydraulic power unit; note that grounding must be mandatory to protect the motor from phase failure and overload; connect cables.

Date: 28.03.2023		AW

Wiring see illustration below.





Figure 5: Electrical connection

The direction of motor rotation depends on the phase sequence. Check 4.2.2 for determining correct phase sequence.

Supply voltage is 380V AC, 50Hz.

Power: 3kW

Current: 6.8A


3.3 Operation of F-HED2008



If there is not enough oil in the hydraulic unit, it can be damaged and smooth operation is no longer possible!

3.3.1 Oil charge

Oil	Ambient temperature	Remark
L-HV32	-18 °C – 60 °C	Recommended
L-HS22	-30 °C – 60 °C	



Oil filler cap

Figure 6: Top view thruster cover

Use a funnel to pour in the oil.

Date: 28.03.2023		AW

Remove the throttle valve cover with a 2mm Allen key and turn the throttle valve clockwise to close it. Open the top cover of the thruster. Unscrew the connections to the pressure gauge and the pressure line slightly for bleeding the thruster.

Operate the hand pump until the oil is pressed out without any signs of air bubbles. Tighten all connections properly and take care that the O-ring of the pressure hose does not get lost.




Figure 7: Throttle valve cover and pressure gauge




Figure 8: Pressure hose connection

Adjust the throttle valve by counter-clockwise (CCW) rotating 3.5 turns until the throttle valve is opened. It can be locked now and the cover can be mounted again.

Fill oil into the oil filler while operating the hand pump until it is leaking slightly. Close the oil filler plug.

Once the hand pump has built up pressure, the oil filler plug must be loosened again to allow the remaining air to escape. Move the unit slightly to the left and right to allow the remaining air to escape. Close the oil filler cap when the hand pump is in the lower position.

Date: 28.03.2023		AW

3.3.2 Commissioning

The F-HED2008 is an independent drive unit, with integrated mechanical, electrical and hydraulic functions. Opening, closing and pressure holding is controlled by the main PLC.

3.3.2.1 Command mode

Power supply command: The supply voltage to the F-HED2008 is provided by the main power supply. The brake gets released when the thruster is energized and it will close when the power supply is cut off.

Control power command: The F-HED2008 is switched on and off via the control line.

3.3.2.2 Working principle

Brake open: The F-HED2008 receives the "Open" command from the main PLC. The motor is energized and drives the pump. The solenoid valves are energized and the pump is building up pressure (brake will be released/opened). As soon as a pre-set pressure is reached, the pressure switch switches off the motor. The brake remains opened.



Brake kept open/released:

The use of poppet valves hermetically seals off the volume flow for a certain time keeping the brake in released condition (motor is still shut off!). As soon as the pressure drops below a pre-set value, the pressure switch gives a signal to start the motor so that the pressure can be built up again.

Brake closed/set:

The command "Close brake" is given by the main PLC. The motor and the solenoid valves are de-energized so that the oil can flow back into the tank and the brake closes.

3.3.2 Manual release operation

	<p>There is no other safety device when the brake is manually released. The drive needs to be secured against any accidental movement.</p>
	<p>Before actuating the manual release lever make sure that the load is secured. In case of lowering suspended loads the brake must be <u>slowly</u> opened to avoid slipping of the load. Direct communication between operator and spotter required.</p>

The brake can be released manually as follows:

Remove the throttle valve cover with a 2mm Allen key and turn the throttle valve clockwise to close it.

Date: 28.03.2023		AW

Take the extension and insert in in the hand pump.



Figure 9: Manual release operation

You can now open the brake by operating the hand pump. Please observe the maximum pressure on the name plate of the brake. This value should not be exceeded. Please check therefore the pressure gauge on the THRUSTER.

To switch back to normal operation, the throttle valve must be opened completely. Adjust the throttle valve by counter-clockwise (CCW) rotating 3.5 turns until the throttle valve is opened. It can be locked now and the cover can be mounted again (with a 2 mm Allen key).

Remove the extension from the hand pump and place it next to the unit.

4. Operation and maintenance

4.1 Pre-operation

The F-HED2008 has been run for about 2500 open/close cycles before delivery (Factory tested).

4.2 Check

4.2.1 Mechanical

Before commissioning, check that the F-HED2008 is free of leaks. Check that the thruster has been screwed down properly. Also check the oil level in the oil sight glass. If the oil level is too low, top up to the specified level.

Note: Overflow valve and pressure switch have been set correctly before delivery, which cannot be adjusted at will. In case certain parameters need to be changed, please contact Furka®.

4.2.2 Electrical

Date: 28.03.2023		AW

Determination of the phase sequence: Check if the pump is running in the right direction by repeatedly switching the drive motor on and off quickly (inching operation) without reaching full speed until it is evident that the pump is working properly. Faultless operation, which can be seen from the noise level of the pressure gauge, should be reached after 30 seconds at the longest.

LED display

The software version will be displayed for 1sec every time the f-HED2008 is powered on.

The standard view shows the number of braking cycles. As soon as an error occurs, the view changes and displays the corresponding information. Please see fig. 10.

Braking cycles

Powered-on times plus 1, LED display XXXXXXXX(XXXXXXX range 0~99999999)



Figure 10: LED display

Fault diagnosis:

Fault	LED display
Motor runs for too long. Continuous operating time of the motor of more than 1 min is detected	Er 1 flickering display period 1s
Motor starts frequently: Motor starts more than 3 times within 5min	Er2 display period 1s
Hardware fault: the input signal of the relay is not consistent with the output signal, the inconsistent time is over 3s	Er4 display period 1s
Oil temperature warning: when the oil temperature of the hydraulic system is detected to be too high	Er5 flickering display period 5s

Status reading

SW1 is the status inquiry button. Press the button briefly several times (less than 5s) to display the errors and error times. To delete the error memory, press the button for longer than 5s. If the button is not pressed for longer than 5s, the display automatically switches to the display of the braking cycles.

A long press (more than 5s) takes you to the input and output parameter query and a single short press (less than 5s) takes you back to braking times.

LED indicator lights

LED1 is the power indicator light, LED3 is the running indicator light, LED4 is the motor running light, LED5 is the fault indicator light.

Date: 28.03.2023		AW

5. Trouble shooting

5.1 Motor cannot be started

- Check oil level and temperature
- Check electrical power supply (incl. control power supply) and wiring
- Check wiring of pressure switch 12 (Contact)
- Check if the motor is damaged

5.2 F-HED2008 does not provide enough power, brake cannot be released

- check if the motor is running (phase sequence ok?)
- check for correct installation (no jamming)
- check oil level and bleeding status
- check setting of overflow valve (10) and pressure switch (12)
- check if the solenoid valves are energized
- check for damaged seals

5.3 Motor starts frequently

- check if the solenoid valves (10) are energized (stable power supply wiring of the coils)
- Check for leakages

5.4 Motor starts continuously

- Check 5.2
- Check pressure switch (12)
- Check control board

Date: 28.03.2023		AW

5.5 Troubleshooting

Nr.	Fault	Troubleshooting
1	Er1, Er2	1. Check for leakages
		2. Check cables and cable connection
		3. Replace pressure switch and temperature switch
		4. Replace MD01 board
2	Er4	1. Check cable and cable connection
		2. Replace MD01 board
3	Er5	1. Check cable and cable connection
		2. Check temperature switch
		3. Replace MD01 board
4	Key and display fault	1. Check cables and cable connection
		2. Replace MD01 board
5	Motor cannot be started	1. Check cable and cable connection
		2. Check motor protection switch for blown fuses
		3. Replace pressure switch, temperature switch and solid state relay
		4. Replace MD01 Board
		5. Replace motor

5.6 Common errors during commissioning

- Filling with unfiltered oil.
- No correct bleeding of the hydraulic unit/system.
- No documentation of the setting values.
- The tank was not filled with (enough) oil before commissioning.
- Abnormal pump noises are not observed (leaking suction line, too much air in the oil).
- Setting of the pressure relief valves with too little distance to the working pressure.
- Pump pressure regulator is set higher or the same as the pressure relief valve.

Date: 28.03.2023		AW



5.7 Disposal

The disposal of the individual materials must be carried out in accordance with the legal and national regulations of your country or your company's internal specifications. If the hydraulic unit is to be decommissioned and scrapped, the remaining hydraulic fluid must first be carefully drained from all parts of the unit.

Special attention must be paid to the disposal of the pressure fluid and to components with residual pressure fluid. When disposing of the pressure fluids, observe the instructions in the safety data sheet.

The hydraulic unit to be scrapped should be dismantled into its individual parts and disposed of separately according to the various materials in accordance with the applicable regulations. Dismantling should be carried out by competent personnel. There are no special dangers as long as suitable tools and equipment are used.

Date: 28.03.2023		AW

6. Annex

Tightening torques acc. to VDI 2230-1:2015

Bolts with metric standard thread:

Spanner size of hex bolts

Screws with external hexagonal round:

Socket-head cap screws:

Bore "medium"

DIN ISO 68, DIN ISO 724, DIN 13-19

DIN EN ISO 4014 bis DIN EN ISO 4018

DIN 34800

DIN EN ISO 4762

DIN EN 20273

$\mu=0.12$

$\mu=\mu_G=\mu_K$

Friction on the thread / head rest

Metric Class

8.8

10.9

12.9

Nmft-lbNmft-lbNmft-lb

M31.31.01.911.42.241.7

M3.52.011.482.962.183.462.55

M42.992.24.393.25.143.8

M55.94.358.666.3910.17.45

M610.27.51511.117.512.9

M824.718.236.326.842.431.3

M1048.635.87152.48462.0

M12846212391144106

M1413398.1195143.8229168.9

M16205151301222353260

M18295217.6420309.8491362.1

M20415306591436692510

M22567418.2808596.0946697.7

M2471552710187511191878

M271054777.415011107.117561295.2

M30143210562040150523871761

M3319341426.427552032.032242377.9

M36248918363544261441483059

M39321623724581337953603953

Spanner size

acc. to ISO 4014 etc.

acc. to DIN

mmmm

5.55.5

66

77

88

1010

1313

1617

1919

2122

2424

2727

3030

3432

3636

4141

4646

5050

5555

6060

Tightening torques

Date: 28.03.2023		AW



Furka Antriebstechnik GmbH
IHW Park, Gebäude T/EG
Eiserfelder Str. 316
57080 Siegen

T +49 271 338894 70

www.furka-antriebstechnik.de

Date: 28.03.2023		AW